

TH-Series Headphones Parts List

[illegible]

No.	Description	TH900	TH600	TH500RP	TH900MK2	TH900MK2 (SB)	TH610	TH-X00/PH/EB (US only)
	FXJ	539348	-	-	606996	623861	-	-
	FHP	547535	563496	586308	606583	606583	606560	603082 610798 612628
29	SCREW Ø 2X2.5	8204552288 552288						
30	SCREW Ø 2X4	8204552287 552287						
31	SHAFT-L	1420439670 439670			-			
32	SHAFT-R	1420439671 439671			-			
33	HANGER	8510002000 615647						
34	SLIDER RING A	1412442488 442488						
35	SPRING HOLDER ASSY	8560444044 444044						
36	SCREW M2L4	8204597750 597750						
37	SLIDER COVER R	N/A 564758	N/A 567781	N/A 591344	1412603318 603318			
38	OUTER BUSH L	-			1412606562 606562		-	-
39	OUTER BUSH R				1412606563 606563			
40	STOPPER				1412606564 606564			
41	CORD ASSY SPRING A				8277765001 608590	-		
42	CORD ASSY SPRING B				8277765002 608591			
43	SPRING CONTACT A				-		8214443001 606802	
44	SPRING CONTACT B						8214443002 606803	
45	BRIDGE CABLE FOR DRIVER						-	
46	SPACER HOUSING TH900	8216957000 554180	-	-	8216957000 554180	-	-	-
47	PACKING CORD TH900MK2	-	-	-	8216995000 609439	8216995000 609439	-	-
48	PACKING CORD TH900MK2	-	-	-	-	8216995000 609439	-	-